



TOP VIEW



SIDE VIEW



ONE WIRE ROPE TO UTILIZE BOTH UP & DOWN
WILL REQUIRE 1 ROPE UP & DOWN ATTACHED
TO HOIST DRUMS NO ROPE CLIP REQUIRED
AT SHUTTER ADJUSTMENT POINT